

# Neptune Paints

## By Neptune Classics

---

These instructions are provided in good faith but without warranty.

### 1. Surface preparation

Remove any sharp edges or flaking paint by using the fine sand paper. It is not necessary to sand down to bare wood, just sand enough to a smooth finish. In cases where the paint surface is not broken, just lightly sand with fine sand paper to take the sheen off of the surface. Vacuum or wipe away any debris.

### 2. Filling

For damage where the surface of the paint is dented or cracked you will need to fill the area with a wood filler. Squeeze the filler directly from the tube into the gap. Remove any residual filler and smooth over with an application spreader. Follow the instructions shown on the filler for drying times.

### 3. Paint preparation

When the filler has dried it will need to be sanded smooth to match the level of the surrounding paint. It should feel seamless to the touch when sanded properly. The area then needs to be cleaned of any dust & debris.

### 4. Painting

Neptune water based eggshell paint can be applied directly onto exposed wood, filler and existing painted surfaces. Firstly make sure the paint is fully mixed. We normally recommend painting an entire panel to ensure that there is no noticeable colour variation. Apply two coats of paint in the direction of any existing brush strokes. When dry the painted area should blend into the existing surface. Brushes should be rinsed with cold tap water to clean.

### Important Note

**Before application please check for colour accuracy. When more than one tin of the same colour is used ensure the batch numbers are identical or intermix before use. We can accept no liability for any decorating costs caused as a result of a miss-match in colours applied beyond the value of the goods delivered by us.**