

# Painted Garden Furniture Care

## By Neptune Classics

---

Thank you for purchasing a Neptune product, we hope it will bring you years of enjoyment. To get the best from this Neptune product please read the details below.

All timber, when exposed to moisture and changes in temperature has a tendency move slightly sometimes causing hairline cracks to appear. This is a perfectly natural process and you may notice cracks opening and closing in your furniture as the seasons change. This is part of the process of your wood furniture stabilizing in the outdoor environment and will in no way affect the strength or longevity of your furniture.

### **MAINTENANCE**

After several seasons the finish on your furniture may need to be refurbished. This is expected for a painted product that is outside for an extended period. To refurbish an item it should first be sanded back, to either bare wood or to take the top of the existing paint off. If sanding back to bare wood Neptune primer should then be used to re-seal the wood. Neptune water based eggshell should then be painted on the primed surface or on the existing paint. Two coats are usually sufficient, remembering to lightly sand between coats.

---

Now all you need to do is sit back and allow your new furniture to become an integral part of your home and lifestyle. We hope you enjoy your furniture as much as we did designing and making it!

Best Wishes  
The Neptune Team

p.s  
Our design team would love to hear your comments. Email us now at [info@neptune.co.uk](mailto:info@neptune.co.uk)

